

Do you know where your child is?

We are WeBond Inc. We are a group of concerned fathers and mothers; we are engineers and entrepreneurs from the Silicon Valley. Family safety is our major goal. Families cannot be happy when over 470,000 children are reported missing according to FBI records annually in the United States alone, that is over 50 children every single hour! That is a very scary statistic.

We decided we needed to do something to protect children from disappearing every day. Our team is formulated from a group of entrepreneur men and women, developers, and engineers many of whom are parents themselves. We decided to put our expertise in the service of family safety. As a result of that, we are launching our first solution for tracking children and keeping them connected to their parents at all times. With this line of products, we will keep children safe and give parents the peace of mind that they deserve.

Contact Us

3080 Olcott St, Ste B220
Santa Clara, CA 95054

Phone: 669-400-9590
Email: support@webondinc.com
Web: <http://www.webondinc.com/>

GPS Phone and Watch Manual



WEBOND, INC

Version 0.8

Webond, Inc
3080 Olcott St, Ste B220
Santa Clara, CA 95054

Table of Contents

Our Products and Services.....	1
Product Introduction	2
Setting up the App	3
Download the Android App.....	3
Download the IOS App.....	3
Initial Setup	3
Operation Guide	4
Activating your SIM card	4
Associating the Device with the App	4
Adding Your Information	5
Additional Settings.....	6
Device Menu.....	7
Warranty	8
Our Mission	9

Our Mission

In addition to linking families together, we also strive to help children develop new habits through our to-do list app which will keep children engaged with their parents throughout the day. WeBond Inc was created to link children to their parents 24 hours a day, 7 days a week. The WeBond team aims to keep you bonded to your loved ones all the time. We strive to keep your children safe and connected while they have fun and play anytime, anywhere.

Contacts

Add contacts information, up to 12, that the child can call.

Pedometer

Track your child's activity during any day or week.

Message Center

This is where all the alarms are. You can find messages when the child is out of the safe zones, when they have taken off the device, proximity alarms and low battery alarms.

Warranty

Instructions before requesting product service.

Please follow:

- The user manual instructions
- Instructions to contact WeBond through email.
- A technical support specialist instruction to get your issue resolved

In case your product does not operate and our technical support cannot resolve your issue, they will guide you through the instructions for the return process.

What does the product limited warranty cover?

Please see additional details on the website at <http://webondinc.com/warranty/>

Our Products & Services

Product Introduction

This section of the manual is a brief introduction about the product and what it can do.

Setting up the App and the Watch/Phone

This section of the manual shows you how to download the App for the iOS and Android devices. It also instructs you on how to enable the SIM and to install it in the Watch/Phone. Finally, this section provides instruction on how to connect the Watch/Phone to the App.

Operation Guide

This section is a full operation guide explaining all the different uses of the device and how to add your contacts. It explains how to use the Watch/Phone and how the App functions from the parent's point of view.

Product Introduction

The Watch/Phone has many features that will enhance your and your child's life and make it easy for you to stay in touch with each other.

The App allows you as a parent to control the content of the Watch/Phone and to know where your child is at any time.

Key Features

On the App homepage, you can program in your number, your spouse's number and any other number that the child can contact immediately. This is done from the Center bottom + button. Once the device syncs these numbers are uploaded to the Watch/Phone.

The Bluetooth symbol on the homepage allows you to keep close proximity of the child in a crowded area. See the message center menu item.

The child can call you with a touch of the screen at any time.

Other Features

Track the child's activity through the pedometer.

Upload the child's class schedule to the device.

Set alarms to remind the child of chores or activities they need to do.

Set boundaries for where the child should be.

The Device Menu



The device menu is accessible from the homepage. Choose the device you want from the drop-down on the home page and then click on the top left corner for this menu.

On this page, you can set alarms for the device, provide access to this device for another adult family member, define safe zones for the device, put in your child's schedule, manage the contacts that your child can call, see the number of steps your child did on any day and access the message center for this particular device.

Alarm Menu

You can manage multiple alarms on device using this menu. These alarms will go off on the Watch/Phone at the designated time to remind your child of an activity that you agreed on.

Device Management

On this page, you can allow other users to access the same Watch/Phone.

Safe Zone

On this page, Safe-zones can be defined for the child to be in. Just click on the plus button on the top right corner and define the area and name it. It will upload to the Watch/Phone.

Syllabus

Here a parent can add the class schedule of the child to know where they should be in school at what time. Just click on each day and add the time. Turn on the switch on the top right to edit the schedule, then turn it off after it is done to prevent accidental changes to it.

Additional Settings

Additional menu items from the settings page include:

Reset Password

That is used to change your current account password

System Reset

This will reset the account to a pristine state to allow you to start over.

Firewall Protection Switch

This is to allow your data to remain anonymous on public networks. It is defaulted to off.

Taken-off alarm

This switch sends an alarm to your app when you child has taken off the watch.

Clean Buffer

This allows you to reset the message buffer if you desire.

Push Text Switch

Device Recording Alarm

SOS Alarm

Enter Safe-Zone Alarm

This turns on the alarm if your child moves into the set safe zones.

Beyond Safe-Zone Alarm

This turns on the alarm if your child moves outside the set safe zones

Bluetooth Anti-Lost Alarm

This turns on the alarm for you to find the watch when it is lost (within range of your phone's Bluetooth).

Setting up the App

Download the Android App



If you have an Android based phone use the camera to scan the code at the left to go to the Google Play store.

Download and install the App.

Download the iOS App



If you have an iOS based phone use the camera to scan the code at the left to go to the App Store.

Download and install the App.

Initial setup



Launch the App on your phone and create a username and password. Make sure you write them down someplace. Click Register to register your username. For ease of use, click Remember Me. You may also want to click Login Auto to avoid having to enter your password.

Login to your account.

Operation Guide

Activating your SIM card

WeBond has shipped your Watch/Phone with a prepaid SIM card from SpeedTalk. You will find it in the box.

Go to <http://www.activatespeedtalk.com> to activate your SIM card. Instructions are on the website.

Once activated, the card will need to be topped off occasionally to continue using the service.

Alternately, if you have a T-mobile family plan, you can add another telephone line and use that SIM card. Be sure to ask for a full-service line, not a data plan, since the device is a fully functional telephone.


You can install the SIM card on the phone by following these steps.

- Remove the back cover of the Watch/Phone
- Slide the SIM tray holder and lift its end up
- Insert the SIM card correctly noting the edge cutout
- Put the SIM tray holder down over the SIM card.
- Slide the SIM tray holder so that it locks the SIM card in place.

Once the SIM card is in place and locked and before you replace the cover on the Watch/Phone, you can now associate this particular device with the App. See the following section.

Associating the Watch/Phone with the App

On the back of cover, you will see a QR code. This is the code that is used to associate each device to the account.




Launch the App on your phone and login.

On the main page with the map, click in the middle of the top bar. A dropdown will show you the connected devices, if any, and a choice to add a Children Watch. Click that. It will open the camera to scan the QR code in the back cover. Scan it.

The watch is now associated with this account.

From this drop-down menu, you can associate other Watch/Phone devices for your other children. The current map shows the device location of the named device. To assist you better to know who the device is tracking do the following.



With the correct device chosen on the drop-down menu on the homepage, click the top right corner of the app to choose the right-hand device menu. On the bottom of that menu is a purple gear button labelled settings.

Click the settings button. The menu shown on picture on the left.

Choose the first selection and put your child's name to associate it with the Watch/Phone.

Adding your information

From the same settings menu above, you can also click on the gray personal button. On the following screen, you can set up your username (from the login), your nickname, gender, birthday and mobile number.